

-13 & P

Table A.1 Page-Based TM Requirements Matrix for SATS

TM Content	-10	-12 -12&P	-13 -13&P	-14 <del>14</del>	MIL-STD-40051 Reference	Element Name
<b>FRONT MATTER</b>	R	R	R	R	5.3.1	<paper.fmt>
Front cover	R	R	R	R	5.3.1.1	<fntcover>
Warning summary					5.3.1.2	<warnsum>
Change transmittal page					5.3.1.3	<chgsheet>
List of effective pages / work packages	R	R	R	R	5.3.1.4	<loepwp>
Title block page	R	R	R	R	5.3.1.5	<titleblk>
Table of contents	R	R	R	R	5.3.1.6	<contents>
How to use this manual	R	R	R	R	5.3.1.7	<howtouse>
<b>CHAPTER 1. GENERAL INFORMATION, EQUIPMENT DESCRIPTION AND THEORY OF OPERATION</b>	R	R	R	R	1-5.1	<gim>
<b>GENERAL INFORMATION WORK PACKAGE</b>	R	R	R	R	1-5.2	<ginfowp>
Scope	R	R	R	R	1-5.2.1	<scope>
Maintenance forms, records, and reports	R	R	R	R	1-5.2.3	<mfrf>
Reporting equipment improvement recommendations (EIR)	R	R	R	R	1-5.2.4	<eir>
Hand receipt (HR) manuals					1-5.2.5	<handreceipt>
Corrosion prevention and control (CPC)	R	R	R	R	1-5.2.6	<cpdata>
Ozone depleting substances (ODS)					1-5.2.7	<odsdata>
Destruction of Army materiel to prevent enemy use	R	R	R	R	1-5.2.8	<destructmat>
Preparation for storage or shipment	R	R	R	R	1-5.2.9	<psref>
Warranty information			R	<del>R</del>	1-5.2.10	<wrtymref>
Nomenclature cross-reference list			R	<del>R</del>	1-5.2.11	<nomenreflist>
List of abbreviations/acronyms	R	R	R	R	1-5.2.12	<loa>
Quality of material	R	R	R	R	1-5.2.14	<qual.mat.info>
Safety, care, and handling	R	R	R	R	1-5.2.15	<sftyinfo>
Nuclear hardness			NR	<del>R</del>	1-5.2.16	<hcp>
Calibration			R	<del>R</del>	1-5.2.17	<calref>
Copyright credit line			NR	<del>R</del>	1-5.2.23	<copyrt>
Supporting information for repair parts, special tools, TMDE, and support equipment	NR		NR	<del>R</del>	1-5.2.24	<supdata>

Table A.1 Page-Based TM Requirements Matrix for SATS

TM Content	-10	-12 -12&P	-13 -13&P	<del>14</del>	MIL-STD-40051 Reference	Element Name
<b>EQUIPMENT DESCRIPTION AND DATA WORK PACKAGE</b>	R	R	R	R	1-5.3	<descwp>
Equipment characteristics, capabilities, and features	R	R	R	R	1-5.3.1	<eqpinfo>
Location and description of major components	R	R	R	R	1-5.3.2	<locdesc>
Differences between models			NR	<del>R</del>	1-5.3.3	<eqpdiff>
Equipment data	R	R	R	R	1-5.3.4	<eqpdata>
Equipment configuration					1-5.3.5	<eqpconfig>
<b>THEORY OF OPERATION WORK PACKAGE</b>	R	R	R	R	1-5.4	<thrywp>
<b>CHAPTER X. OPERATOR INSTRUCTIONS</b>	R	R	R	R	2-5.1	<opim>
<b>DESCRIPTION AND USE OF OPERATOR CONTROLS AND INDICATORS WORK PACKAGE</b>	R	R	R	R	2-5.2.2.2	<ctrlindwp>
<b>OPERATION UNDER USUAL CONDITIONS WORK PACKAGE</b>	R	R	R	R	2-5.2.2.3	<opusualwp>
Security measures for electronic data	R	R	R	R	2-5.2.2.3.1	<secref>
Siting requirements					2-5.2.2.3.2	<site>
Shelter requirements					2-5.2.2.3.3	<shelter>
Assembly and preparation for use					2-5.2.2.3.4	<prepforuse>
Initial adjustments, before use and self-test					2-5.2.2.3.5	<initial>
Operating procedures	R	R	R	R	2-5.2.2.3.6	<oper>
Decals and instruction plates					2-5.2.2.3.6.2	<instructplt>
Operating auxiliary equipment					2-5.2.2.3.7	<operaux>
Preparation for movement					2-5.2.2.3.8	<prepmove>
<b>OPERATION UNDER UNUSUAL CONDITIONS WORK PACKAGE</b>	R	R	R	R	2-5.2.2.4	<opunuwp>
Security measures for electronic data	R	R	R	R	2-5.2.2.4.1	<secref>
Unusual environment / weather	R	R	R	R	2-5.2.2.4.2	<unusualenv>
Fording and swimming					2-5.2.2.4.3	<fording>
Interim nuclear, biological, and chemical (NBC) decontamination procedures					2-5.2.2.4.4	<decon>
Jamming and electronic countermeasures (ECM) procedures					2-5.2.2.4.5	<ecm>
Emergency procedures	R	R	R	R	2-5.2.2.4.6	<emergency>

MIL-STD-40051B(TM)

Table A.1 Page-Based TM Requirements Matrix for SATS

TM Content	-10	-12 -12&P	-13 -13&P	<del>14</del>	MIL-STD-40051 Reference	Element Name
STOWAGE AND DECAL / DATA PLATE GUIDE WORK PACKAGE			NR	<del>FE</del>	2-5.2.2.5	<stowagewp>
ON-VEHICLE EQUIPMENT LOADING PLAN WORK PACKAGE			O	<del>FE</del>	2-5.2.2.6	<eqploadwp>
CHAPTER X. TROUBLESHOOTING PROCEDURES		R	R	R	3-5.3	<tim>
TROUBLESHOOTING INDEX WORK PACKAGE			R	<del>FE</del>	3-5.3.3.2	<tsindxwp>
OPERATIONAL CHECKOUT WORK PACKAGES					3-5.3.3.6.3	<opcheckwp>
TROUBLESHOOTING PROCEDURES WORK PACKAGES					3-5.3.3.6.4	<tswp>
OPERATIONAL CHECKOUT AND TROUBLESHOOTING PROCEDURES WORK PACKAGES					3-5.3.3.6.5	<opcheck-tswp>
CHAPTER X. MAINTENANCE INSTRUCTIONS	R	R	R	R	4-5.3	<mim>
SERVICE UPON RECEIPT WORK PACKAGE	NR	R	R	R	4-5.3.2.1	<surwp>
Siting	NR				4-5.3.2.1.1	<siting>
Shelter requirements	NR				4-5.3.2.1.2	<shltr>
Service upon receipt of materiel	NR				4-5.3.2.1.3	<surmat>
Installation instructions	NR				4-5.3.2.1.4	<install>
Preliminary servicing of equipment	NR				4-5.3.2.1.5	<preserv>
Preliminary checks and adjustment of equipment	NR				4-5.3.2.1.6	<prechkadj>
Preliminary calibration of equipment	NR				4-5.3.2.1.7	<precal>
Circuit alignment	NR				4-5.3.2.1.8	<calign>
Ammunition markings	NR				4-5.3.2.1.9	<ammo.markings>
Classification of defects	NR				4-5.3.2.1.10	<ammo.defect>
Ammunition handling	NR				4-5.3.2.1.11	<ammo.handling>
Procedures to activate ammunition	NR				4-5.3.2.1.12	<arm>
EQUIPMENT / USER FITTING INSTRUCTIONS WORK PACKAGE (PERSONAL USE EQUIPMENT)	NR		NR	<del>FE</del>	4-5.3.2.2	<perseqwp>
PMCS INTRODUCTION WORK PACKAGE	R	R	R	R	4-5.3.2.3.1	<pmcsintrowp>
PMCS, INCLUDING LUBRICATION INSTRUCTIONS, WORK PACKAGE	R	R	R	R	4-5.3.2.3.2	<pmcswp>

Table A.1 Page-Based TM Requirements Matrix for SATS

TM Content	-10	-12 -12&P	-13 -13&P	-14 <del>14</del>	MIL-STD-40051 Reference	Element Name
<b>MAINTENANCE WORK PACKAGES</b>	R	R	R	R	4-5.3.2.4	<maintwp>
<b>NOTE</b> <i>As applicable, the following maintenance tasks shall be presented in the general order listed below:</i>						
Servicing					4-5.3.2.4.1.3	<service>
Ground handling					4-5.3.2.4.1.4	<groundtsk>
Inspection of installed items					4-5.3.2.4.1.5	<inspinstitm>
Removal					4-5.3.2.4.1.6	<remove>
Disassembly					4-5.3.2.4.1.7	<disassem>
Cleaning					4-5.3.2.4.1.8	<clean>
Inspection - acceptance and rejection criteria					4-5.3.2.4.1.9	<acptrejinsp>
Nondestructive testing inspection (NDTI)					4-5.3.2.4.1.10	<ndti>
Repair or replacement					4-5.3.2.4.1.11	<repair-rplc>
Alignment					4-5.3.2.4.1.12	<align>
Painting					4-5.3.2.4.1.13	<paint>
Lubrication					4-5.3.2.4.1.14	<lube>
Assembly					4-5.3.2.4.1.15	<assem>
Test and inspection					4-5.3.2.4.1.16	<test-inspect>
Installation					4-5.3.2.4.1.17	<install>
Adjustment					4-5.3.2.4.1.18	<adjust>
Calibration					4-5.3.2.4.1.19	<calibration>
Radio interference suppression					4-5.3.2.4.1.20	<ris>
Placing in service					4-5.3.2.4.1.21	<pis>
Testing					4-5.3.2.4.1.22	<test-pass>
Preparation for storage or shipment					4-5.3.2.4.1.25	<pss>
Classification of defects					4-5.3.2.4.1.26	<ammo.defect>
Handling ammunition					4-5.3.2.4.1.27	<ammo.handling>
Ammunition markings					4-5.3.2.4.1.28	<ammo.markings>
Procedures for ammunition activation					4-5.3.2.4.1.29	<arm>
<b>GENERAL MAINTENANCE WORK PACKAGE</b>			R	<del>R</del>	4-5.3.2.5	<gen.maintwp>
<b>ILLUSTRATED LIST OF MANUFACTURED ITEMS WORK PACKAGE</b>	NR		O	<del>O</del>	4-5.3.2.7	<manuwp>
<b>TORQUE LIMITS WORK PACKAGE</b>	NR		NR	<del>NR</del>	4-5.3.2.8	<torquewp>

MIL-STD-40051B(TM)

Table A.1 Page-Based TM Requirements Matrix for SATS

TM Content	-10	-12 -12&P	-13 -13&P	<del>-14</del> <del>-14&amp;P</del>	MIL-STD-40051 Reference	Element Name
WIRING DIAGRAMS WORK PACKAGE	NR		R	<del>R</del>	4-5.3.2.9	<wiringwp>
CHAPTER X. AUXILLARY EQUIPMENT MAINTENANCE INSTRUCTIONS			NR	<del>R</del>	4-5.3	<mim>
AUXILLARY EQUIPMENT MAINTENANCE WORK PACKAGE			NR	<del>R</del>	4-5.3.2.11	<auxeqwp>
ILLUSTRATED LIST OF MANUFACTURED ITEMS WORK PACKAGE	NR		NR	<del>R</del>	4-5.3.2.7	<manuwp>
TORQUE LIMITS WORK PACKAGE	NR		NR	<del>R</del>	4-5.3.2.8	<torquewp>
WIRING DIAGRAMS WORK PACKAGE	NR		NR	<del>R</del>	4-5.3.2.9	<wiringwp>
CHAPTER X. AMMUNITION MAINTENANCE INSTRUCTIONS			NR	<del>R</del>	4-5.3	<mim>
AMMUNITION MAINTENANCE WORK PACKAGE			NR	<del>R</del>	4-5.3.2.12.1	<ammowp>
AMMUNITION MARKING INFORMATION WORK PACKAGE	NR		NR	<del>R</del>	4-5.3.2.12.2	<ammo.markingwp>
FOREIGN AMMUNITION (NATO) WORK PACKAGE	NR		NR	<del>R</del>	4-5.3.2.12.3	<natowp>
CHAPTER X. SUPPORTING INFORMATION  <i>NOTE</i> <i>Applicable supporting information work packages shall be arranged in the order in which they are presented here and numbered accordingly.</i>	R	R	R	R	6-5.1	<sim>
REFERENCES WORK PACKAGE	R	R	R	<del>R</del>	6-5.2	<refwp>
INTRODUCTION FOR STANDARD FORMAT MAC WORK PACKAGE	NR	R	R	<del>R</del>	6-5.3.1	<macintrowp>
MAC WORK PACKAGE	NR	R	R	<del>R</del>	6-5.3.3	<macwp>
RPSTL WORK PACKAGE (-10 THROUGH -14) (-12&P THROUGH -14&P)	NR NR	NR R	NR R	<del>R</del>	6-5.4	<rpstlwp>
COMPONENTS OF END ITEM (COEI) AND BASIC ISSUE ITEMS (BII) LISTS WORK PACKAGE	R	R	R	<del>R</del>	6-5.5	<coeibiiwp>
ADDITIONAL AUTHORIZATION LIST (AAL) WORK PACKAGE			NR	<del>R</del>	6-5.6	<aalwp>

MIL-STD-40051B(TM)

Table A.1 Page-Based TM Requirements Matrix for SATS

TM Content	-10	-12 -12&P	-13 -13&P	-14 -14&P	MIL-STD-40051 Reference	Element Name
EXPENDABLE AND DURABLE ITEMS LIST WORK PACKAGE	R	R	R	R	6-5.7	<explistwp>
TOOL IDENTIFICATION LIST WORK PACKAGE	NR		NR	NR	6-5.8	<toolidwp>
MANDATORY REPLACEMENT PARTS WORK PACKAGE	NR		NR	NR	6-5.9	<mrplwp>
CRITICAL SAFETY ITEMS AND FLIGHT SAFETY CRITICAL AIRCRAFT PARTS WORK PACKAGE			NR	NR	6-5.10	<csi.fscap.wp>
SUPPORT ITEMS WORK PACKAGE			NR	NR	6-5.11	<supitemwp>
ADDITIONAL SUPPORTING WORK PACKAGES			NR	NR	6-5.12	<genwp>
REAR MATTER	R	R	R	R	5.3.2	<rear>
Glossary			R	R	5.3.2.1	<glossary>
Alphabetical index			R	R	5.3.2.2	<aindx>
Foldout pages			D	D	5.3.2.3	<foldsect>
DA Form 2028	R	R	R	R	5.3.2.4	<da2028>
Authentication page	R	R	R	R	5.3.2.5	<authent>
Back cover	R	R	R	R	5.3.2.6	<back>

Legend

- R Required
- NR Not Required
- O Optional
- Shaded As Required

INSTRUCTIONS FOR REQUISITIONING PARTS  
FROM COMMERCIAL SOURCES

The supply officer shall identify the prime manufacturer of the repair part by Commercial and Government Entity (CAGE) Code Number and requisition the repair part from the prime manufacturer. When requisitioning parts from commercial sources, it is mandatory that the following information be provided the supply officer by the unit.

1. Commercial And Government Entity (CAGE) Code Number.
2. Manufacturer's Part Number - Exactly as listed in the commercial literature.
3. Nomenclature - Exactly as listed in the commercial literature, including dimensions if available.
4. Manufacturer's Model Number.
5. Manufacturer's Serial Number - (End Item).
6. Any additional information such as type, size, thread, frame number, and electrical characteristics.

*Encl 2*





REPLY TO  
ATTENTION OF

**DEPARTMENT OF THE ARMY**  
USAMC LOGISTICS SUPPORT ACTIVITY  
REDSTONE ARSENAL, ALABAMA 35898-7466

29 MAY 2003

AMXLS-AP

MEMORANDUM FOR SEE DISTRIBUTION:

SUBJECT: Interim Guidance for Preparing Technical Manuals for Systems With Two-Level Maintenance Concept

1. The following guidance is provided for your use in preparing technical manuals for systems using the new two-level maintenance concept:

a. The two levels are field and sustainment:

(1) Field maintenance is on-system maintenance and is mainly replacement of defective parts and preventative maintenance. Field maintenance returns repaired equipment to the soldier. It covers crew, unit, and selected DS maintenance tasks. Some "off-system" maintenance can be done at field level if, based on task analysis, it is simple to complete or it is critical to mission readiness.

(2) Sustainment is off-system maintenance and is mainly repair of defective equipment/parts. Sustainment maintenance returns repaired equipment/parts to the supply system. It covers selected DS tasks, GS, and Depot maintenance.

b. DS/GS tasks must be analyzed to determine whether they will be done at field or sustainment level.

c. All new as well as selected current systems will be using two-level maintenance. As the two-level maintenance doctrine continues to evolve TRADOC will identify Units of Action (UA) that will transition to the two-level maintenance concept. Equipment listed on the Table of Organizational Equipment (TOE) associated with the identified UA will be required to transition to the two-level maintenance structure. Technical Manuals for these systems must be prepared using MIL-STD-40051. The only content changes required are in the maintenance allocation chart (MAC). Enclosure 1 contains a sample introduction and MAC to support the two-level maintenance concept. The maintenance level, in the work package header information for the operator/maintenance/troubleshooting task, would be field (unit), field (DS), sustainment (GS) or sustainment (depot).

d. The TM numbers will be done in accordance with DA PAM 25-40 as they currently are done. There will not be a change in how TMs are numbered at this time.




AMXLS-AP

SUBJECT: Interim Guidance for Preparing Technical Manuals for Systems With Two-Level Maintenance Concept

2. This interim guidance will be incorporated into revision "C" to MIL-STD-40051 and will remain in effect until the revision is completed.

3. Point of contact is John Zibell, DSN 645-9852; e-mail address, john.zibell@logsa.redstone.army.mil.



JOHN E. PEER  
Chief, Engineering, Logistics, and Field  
Support Center  
Logistics Support Activity

Encl  
as

**DISTRIBUTION:**

US Army Materiel Command (AMCIO-R), 5001 Eisenhower Avenue, Alexandria, VA  
22333-0001

US Army Materiel Command (AMCOPS), 5001 Eisenhower Avenue, Alexandria, VA  
22333-0001

US Army Research, Development and Engineering Center (AMSTA-AR-WEL-S), Building 1,  
Picatinny Arsenal, NJ 07806-2739

US Army Aviation and Missile Command (AMSAM-MMC-MA-NP), Redstone Arsenal, AL  
35898-5238

US Army Communications-Electronics Command (AMSEL-LC-LEO-E-ED), Building 1209,  
1st Floor, Rittko Avenue, Fort Monmouth, NJ 07703-5000

US Army Soldier Biological Chemical Command (AMSSB-RIM-L(N)), 15 Kansas Street, Natick,  
MA 01760-5052

US Army Soldier Biological Chemical Command (AMSSB-REN-CW), 5183 Blackhawk Road,  
Aberdeen Proving Ground, MD 21010-5424

US Army Tank-Automotive and Armaments Command (AMSTA-LC-CIP-WT), Rock Island, IL  
61299-7630

US Army Tank-Automotive and Armaments Command (AMSTA-LC-CIL), Warren, MI  
48397-5000

US Army Training and Doctrine Command (ATTG-CD), Fort Monroe, VA 23651-5000

US Army Communications-Electronics Command Communications Security Logistics  
Activity (SELCL-IA-A), Fort Huachuca, AZ 85613-7090

US Army Publishing Agency (JDHQSV-PAP-E), 2461 Eisenhower Avenue, Alexandria, VA  
22331-0302

US Army Combined Arms Support Command (DCD-OD, COL Smith), 3901 A Avenue, Suite  
250, Ft. Lee, VA 23801

Office of the Deputy Chief of Staff for Logistics (DALO-SMM, Mr. Chris Lowman), 500 Army  
Pentagon, Washington, DC 20310-0500

## MAINTENANCE ALLOCATION CHART (MAC) INTRODUCTION

### The Army Maintenance System MAC

This introduction provides a general explanation of all maintenance and repair functions authorized at the two maintenance levels under the Two-Level Maintenance System concept.

The MAC (immediately following the introduction) designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component shall be consistent with the capacities and capabilities of the designated maintenance levels, which are shown on the MAC in column (4) as:

Field — includes two subcolumns, Unit (C (operator/crew) and O (unit) maintenance) and Direct Support ( F) maintenance

Sustainment — includes two subcolumns, general support ( H) and depot (D).

The tools and test equipment requirements (immediately following the MAC) list the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from the MAC.

The remarks (immediately following the tools and test equipment requirements) contain supplemental instructions and explanatory notes for a particular maintenance function.

### Maintenance Functions

Maintenance functions are limited to and defined as follows:

1. Inspect. To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g., by sight, sound, or feel). This includes scheduled inspection and gagings and evaluation of cannon tubes.
2. Test. To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards on a scheduled basis, i.e., load testing of lift devices and hydrostatic testing of pressure hoses.

*Enclosure*

3. Service. Operations required periodically to keep an item in proper operating condition; e.g., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases. This includes scheduled exercising and purging of recoil mechanisms.

4. Adjust. To maintain or regulate, within prescribed limits, by bringing into proper position, or by setting the operating characteristics to specified parameters.

5. Align. To adjust specified variable elements of an item to bring about optimum or desired performance.

---

6. Calibrate. To determine and cause corrections to be made or to be adjusted on instruments of test, measuring, and diagnostic equipment used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

7. Remove/Install. To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

8. Replace. To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and assigned maintenance level is shown as the third position code of the Source, Maintenance and Recoverability (SMR) code.

9. Repair. The application of maintenance services, including fault location/troubleshooting, removal/installation, disassembly/assembly procedures, and maintenance actions to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

#### **NOTE**

The following definitions are applicable to the "repair" maintenance function:  
Services. Inspect, test, service, adjust, align, calibrate, and/or replace.

Fault location/troubleshooting. The process of investigating and detecting the cause of equipment malfunctioning; the act of isolating a fault within a system or Unit Under Test (UUT).

Disassembly/assembly. The step-by-step breakdown (taking apart) of a spare/functional group coded item to the level of its least component, that is assigned an SMR code for the level of maintenance under consideration (i.e., identified as maintenance significant).

Actions. Welding, grinding, riveting, straightening, facing, machining, and/or resurfacing.

10. Overhaul. That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

11. Rebuild. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (e.g., hours/miles) considered in classifying Army equipment/components.

#### **Explanation of Columns in the MAC**

Column (1) Group Number. Column (1) lists FGC numbers, the purpose of which is to identify maintenance significant components, assemblies, subassemblies, and modules with the Next Higher Assembly (NHA).

Column (2) Component/Assembly. Column (2) contains the item names of components, assemblies, subassemblies, and modules for which maintenance is authorized.

Column (3) Maintenance Function. Column (3) lists the functions to be performed on the item listed in column (2). (For a detailed explanation of these functions refer to "Maintenance Functions" outlined above.)

Column (4) Maintenance Level. Column (4) specifies each level of maintenance authorized to perform each function listed in column (3), by indicating work time required (expressed as manhours in whole hours or decimals) in the appropriate subcolumn. This work time figure represents the active time required to perform that maintenance function at the indicated level of maintenance. If the number or complexity of the tasks within the listed maintenance function varies at different maintenance levels, appropriate work time figures are to be shown for each level. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the MAC. The symbol designations for the various maintenance levels are as follows:

**Field:**

C Operator or crew maintenance  
O Unit maintenance  
F Direct support maintenance

**Sustainment:**

H General support maintenance  
D Depot maintenance

**NOTE**

The "L" maintenance level is not included in column (4) of the MAC. Functions to this level of maintenance are identified by a work time figure in the "H" column of column (4), and an associated reference code is used in the REMARKS column (6). This code is keyed to the remarks and the SRA complete repair application is explained there.

Column (5) Tools and Equipment Reference Code. Column (5) specifies, by code, those common tool sets (not individual tools), common Test, Measurement and Diagnostic Equipment (TMDE), and special tools, special TMDE and special support equipment required to perform the designated function. Codes are keyed to the entries in the tools and test equipment table.

Column (6) Remarks Code. When applicable, this column contains a letter code, in alphabetical order, which is keyed to the remarks table entries.

**Explanation of Columns in the Tools and Test Equipment Requirements**

Column (1) Tool or Test Equipment Reference Code. The tool or test equipment reference code correlates with a code used in column (5) of the MAC.

Column (2) Maintenance Level. The lowest level of maintenance authorized to use the tool or test equipment.

Column (3) Nomenclature. Name or identification of the tool or test equipment.

Column (4) National Stock Number (NSN). The NSN of the tool or test equipment.

Column (5) Tool Number. The manufacturer's part number, model number, or type number.

**Explanation of Columns in the Remarks**

Column (1) Remarks Code. The code recorded in column (6) of the MAC.

Column (2) Remarks. This column lists information pertinent to the maintenance function being performed as indicated in the MAC."

**Table 1. MAC for *(Insert system name)***

(1) GROUP NUMBER	(2) COMPONENT/ ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL				(5) TOOLS AND TEST EQUIPMENT	(6) REMARKS CODE
			FIELD		SUSTAINMENT			
			UNIT	DS	GS	DEPOT		
			C	O	F	H		

**Table 2. Tools and Test Equipment for *(Insert system name)***

**Table 3. Remarks for *(Insert system name)***

Enclosure